

When writing
ALWAYS quote your Car Number
(This is under the bonnet on the Tool Box).

The Austin Seven

“NIPPY” SPORTS
MODEL



SPECIAL SPARE PARTS LIST

PRICE 6d.

THE
AUSTIN MOTOR CO. LTD.
LONGBRIDGE :: BIRMINGHAM

PUBLICATION - 1406 NS

TERMS OF BUSINESS

ALL Austin Agents carry stocks of genuine Austin replacements, and application for spare parts should be made to them. Clients will then be certain that the replacement is made by parts supplied by The Austin Motor Company and carrying their high reputation for quality and workmanship.

Correspondence with the Company relating to Spare Parts, Accessories, and Replacements should be addressed to the Service Department.

All Prices are "at works," carriage or postage extra.

Packing cases charged if not returned carriage paid to the Company's works within 28 days.

Quotations hold good for 14 days from date, but those in respect of proprietary articles are subject to any alteration made by the makers in their list prices.

Cash with order, unless purchaser already has an account with the Company or is able to furnish approved references.

Consequent upon the introduction of alterations due to improvements, the Company in no way holds itself liable or responsible as to alteration in details in respect to orders.

The Company retains the right of making alterations to this list without notice, should it be deemed necessary.

Delivery on any specified date is not guaranteed.

TELEGRAPH AND TELEPHONE ORDERS.

To protect itself against fraud, the Company is compelled to decline to deliver goods ordered by telegram or telephone to the address of any persons unknown to it, unless covered by telegraphic remittance.

DAMAGE IN TRANSIT.

The Company does not hold itself responsible for goods lost or damaged in transit. All packages, upon receipt, should be signed for as "unexamined," and in the event of loss or damage to the contents, claim made upon the carriers without delay.

AUSTIN SEVEN Nippy Sports Model

COMMENCING from Chassis No. 257,842 (January, 1937), the engine of the Austin Seven Nippy Sports Model is of the three-bearing crankshaft type. A complete list of the special parts are given below and on the following pages. This list is supplementary to the Standard List.

CRANKCASE

	Number per car.	Part Number.
Crankcase with studs, oil plugs, camshaft front bearing and oil pump spindle bush ...	1	C1-223
Oil Filler Cap ...	1	1A870
Front Cover ...	1	1A559
Cap for starting handle aperture ...	1	9C259
Camshaft Front Bearing ...	1	9E50
Camshaft Centre Bearings ...	1 pr.	9E228
Oil Dipper Rod ...	1	9C224
Oil Pump Bottom Cover ...	1	9C223
Crankcase Bottom Cover ...	1	9E57
Nuts for engine mounting bolt, rear ...	2	2K3995
Washers for engine rear mounting, bottom ...	2	2K4877
Packing Washers for engine mounting ...	4	2K4896
Washers for water pipe setscrew ...	2	2K4958
Oil Pressure Pipe ...	1	1A875

CRANKSHAFT

Crankshaft with end bearings ...	1	C1-224
Crankshaft Gear ...	1	9C76
Crankshaft Oil Cover Plates ...	4	9E229
Setscrews for plates ...	8	2K5297
Lockwashers ...	4	2K5779
Camshaft ...	1	9E226
Camshaft Gear ...	1	9E51
Nut for camshaft gear ...	1	9E31
Lockwasher ...	1	2H665
Camshaft Roller Race ...	1	9E32
Camshaft Rollers ...	9	2K5076

CYLINDERS

Cylinder Head	1	9E1/2K8157
Joint Washer	1	9E15
Cylinders with pistons	1	B8-27
Cylinder Head Studs	2	9E28
Valve Guides	8	9E73
Sparking Plugs	4	2H1713
Connecting Rods Caps and Bearings	4	C1-225
Bolts with pegs	8	9E231/2K6132
Pegs	8	2K6132
Nuts	8	2K8191
Locking Plates	8	9C213
Pistons with rings and gudgeon pins	4	C1-87
Gudgeon Pins	4	9C263
Buttons for gudgeon pins	8	9C264

VALVES AND SPRINGS

Valves, inlet and exhaust	8	9E72
Springs, inner	8	9E75
Springs, outer	8	9E74
Spring Cups	8	9E30
Valve Split Cotters	8 prs.	1A63

FAN, RADIATOR AND STARTING HANDLE

Fan	1	1A418
Fan Belt	1	2H666
Fan Driving Pulley	1	1A420
Fan Pulley	1	1A903
Radiator with filler cap	1	9E103/1A825
Rubber Washer (filler and cowl)	1	2K7203
Water Connection, top	1	1A115
Water Connection, bottom	1	1A276
Starting Handle	1	1A680
Starting Handle Shaft	1	1A564
Starting Handle Spring	1	2K6590
Screw, collar to shaft	1	2K4710

WIRING

Cable complete, battery negative to starter	1	2K8457
Rubber Ferrule for speedometer flex. through dash	1	2H867

PETROL TANK and PIPING

Petrol Tank complete with filler cap	1	B8-32
U-bolts	2	1A587
Petrol Pipe, pump to carburetter	1	9E143
Petrol Pipe, tank to pump, tank end	1	9E203
Petrol Pipe, tank to pump, pump end	1	1A718

INDUCTION, EXHAUST AND SILENCER

Induction Pipe with plugs	1	9E179/2K4865
Joint Washer	1	9E95
Washer for plug	1	2K4956
Setscrews, induction pipe to manifold	4	2K3057
Spring Washers	4	2K1210
Exhaust Manifold	1	9E71
Carburetter	1	2H1232
Joint Washer	1	1B135
Setscrews, carburetter to induction pipe	2	2K3094
Spring Washers	2	2K1211
Silencer with tail pipe and brackets	1	9E78
Clamping Bolt for bracket	1	2K3049
Exhaust Pipe with flange	1	9E122/1A99
Bolts	4	2K3051
Nuts	4	2K4053
Washers	4	2K1202
Silencer Clip, rear	1	9E88
Clamping Bolt for clip	1	2K3061
Bolts, clip to frame	2	2K3046
Nuts	3	2K3975
Washer	1	2K1202
Spring Washers	2	2K1210
Tail Pipe Clip	1	9E89
Bracket, clip to body...	1	9E90
Clamping Bolt for clip	1	2K3051
Bolts, clip to body bracket	2	2K3046
Nuts	3	2K3975
Spring Washers	3	2K1210

ENGINE CONTROLS

Accelerator Pedal	1	1G348
Accelerator Pedal Spindle (L.H. Steering)	1	9E180
Accelerator Control Lever (L.H. Steering)	1	9E181
Bolt for accelerator pedal	1	2K3050
Nut	1	2K3975
Spring Washer	1	2K1210
Accelerator Pedal Spring	1	1A599
Accelerator Control Spindle	1	9E58
Collar for accelerator control spindle	1	2K5383
Setscrew	1	2K3048
Control Spindle Bearings	2	1A144
Nuts	4	2K3976
Spring Washers	2	2K1211
Ball Joints for accelerator control lever connecting link	2	2H22
Ball Coupling (L.H. Steering)	1	2H345
Nuts	2	2K4012
Spring Washers	2	2K1209
Throttle Control Rod	1	2K5410
Locknut	1	2K4012

CAUTION.

Parts of genuine Austin manufacture only should be used when a replacement is made, to ensure that the service given by the original high quality of the car parts shall be maintained by the replacement. Imitations cannot be relied upon to do this.

If imitations are used, the Company's Guarantee is infringed and becomes null and void.

Always get your replacements from Authorized Austin Dealers, as they stock only the genuine Austin Spare Parts.

Should repairs be executed by other than an authorized Austin Dealer, for safety's sake always obtain a guarantee that genuine Austin Spare Parts are used.

INSTRUMENTS AND
DYNAMO GEAR

Dynamo Gear	1	9E175
Setscrews, dynamo casing to front cover	1	2K61
Studs for dynamo casing	2	2K404
Nuts	2	2K1162
Spring Washers	2	2K1210
Battery Cover	1	2H1274
Fixing Nuts	2	2H1275
Cap Nuts	2	2H1276
Operating Knob for starter switch, complete with wire	1	B9-12A & B
Operating Knob with flange and spring only	1	B9-12A
Operating Knob only	1	1A567
Spring	1	2K8934
Flange	1	9E166
Spring Cap	1	9E167
Operating Wire (control end)	1	9E169
Operating Wire (starter end)	1	9E168
Swinging Link and Bracket	1	A1-114
Rubber Ferrule for starter operating wire	1	3F90
Starter Control (L.H. Steering)	1	2H1622
Carburettor Starter Lever Control	1	2H1888
Electric Horn	1	2H1291
Bolt, horn to bonnet stay	1	2K3136
Nut	1	2H3977
Spring Washer	1	2K1212
Oil Pressure Gauge	1	2H1898
Fixing Strap for oil gauge	1	2H1085
Petrol Gauge (gallons)	1	2H1079
Petrol Gauge (litres)	1	2H1830
Speedometer (miles)	1	2H1845
Speedometer (kilometres)	1	2H1846
Speedometer Flexible Drive	1	2H1522
Air Strangler Control, complete	1	B8-34
Air Strangler Cable only (R.H. Steering)	1	2H1273
Air Strangler Cable only (L.H. Steering)	1	2H1675
Rubber Ferrule for strangler wire through dash	1	3B50
Dash Lamp	1	2H1078
Switchbox, Key and Cable Harness	1	2H1789
Ammeter	1	2H1077
Dip Switch with cable	1	2H1296

GEARBOX

Gearbox—R.H. Steering	1	9E218
Gearbox—L.H. Steering	1	9E219
Change Speed Lever	1	9E131
First Motion Shaft with cone	1	B8-18
Laygear complete	1	B8-19
Speedometer Driving Gear	1	1A3145
Speedometer Pinion	1	1A3146

HAND BRAKE

Handbrake Lever with trigger, catch, rod and spring, R.H. Steering	1	B8-5
Handbrake Lever with trigger, catch, rod and spring, L.H. Steering	1	C1-228
Catch Rod—R.H. Steering	1	9E115
Catch Rod—L.H. Steering	1	9E121

STEERING

Steering Wheel	1	1G6066
Traffic and Horn Switch	1	2H1512
Steering Box and outer column	1	1A6112
Inner Column	1	1A6116
Worm Sector—R.H. Steering	1	1A126
Worm Sector—L.H. Steering	1	1A6135
Shim for steering box adjusting screw, .036in. thick	1	2K6810
Shim for steering box adjusting screw, .002in. thick as req'd.	1	2K5320
Shim for steering box adjusting screw, .005in. thick as req'd.	1	2K5321

**STEERING TUBES AND
RADIUS ARMS**

Cross Tube Lever—offside	1	9C135
Cross Tube Lever—nearside	1	9C136
Keys	2	2K2121
Side Tube Lever—R.H. Steering	1	9C134
Side Tube Lever—L.H. Steering	1	9E70
Radius Arm and End—offside	1	B8-63
Radius Arm and End—nearside	1	B8-64
Bolt for radius arm end	1	9C161

FOOT CONTROLS

Brake Pedal Lever—R.H. Steering	1	9E106
Brake Pedal Lever—L.H. Steering	1	1A5108
Brake Pedal Pad	1	1A5033
Brake and Clutch Pedal Nut	1	1A5036
Clutch Pedal Pad	1	1A5035
Clutch Pedal Stop, front	1	9E136
Clutch Pedal Stop, rear	1	9E137
Clutch Pedal Lever—R.H. Steering	1	9E107
Clutch Pedal Lever—L.H. Steering	1	1A3150
Rear Brake Rope	1	C1-112
Guide for rear brake rope	1	1A5019
Brake Cross Tube	1	B6-47
Front Brake Rope—L.H. Steering	1	9E201

**REAR AXLE AND
PROPELLER SHAFT**

Crown Wheel	1	1A7206
Bevel Pinion Shaft	1	1A7240
Propeller Shaft complete	1	1A7227
Elbow for axle case plug	1	9E105
Washer for elbow	1	2K4954
Washer for elbow	1	2K4954
Plug for elbow	1	2K4994
Washer for plug	1	2K7506



FRAME

Frame complete—R.H. Steering	1	B8-57
Frame complete—L.H. Steering	1	C1-231
Side Members	2	1A5240
Front Cross Member—R.H. Steering	1	B8-3
Front Cross Member—L.H. Steering	1	C1-232
Rear Cross Member—R.H. Steering	1	B8-4
Rear Cross Member—L.H. Steering	1	C1-233
Frame Centre Member	1	B8-70
Rear Extension, offside	1	1A5243
Rear Extension, nearside	1	1A5244
Torque Tube Ball Flange	1	1A5181
Bracket for brake rope guide, offside—R.H. Steering	1	9E93
Bracket for brake rope guide, nearside—L.H. Steering	1	9E94
Bracket for brake rope guide, offside front—L.H. Steering	1	9E110
Bracket for brake rope guide, nearside, front—L.H. Steering	1	9E111
Front Road Spring	1	9E220
Front Spring Packing	1	9C143
Front Spring Clips	2	9C101
Lockwashers	2	2K5726
Rear Road Springs	2	9E221
Rear Road Spring, nearside—L.H. Steering	1	9E222
Rear Spring Clips	2	1A5125

SHOCK ABSORBERS

Front Shock Absorber Bracket	1	1A5067
Bolts, shock absorber bracket to front spring bracket	2	2K3095
Nuts	2	2K3976
Spring Washers	2	2K1211
Rear Connecting Links	2	B8-6
Rear Shock Absorber Bracket on frame, offside	1	1A5121
Rear Shock Absorber Bracket on frame, nearside...	1	1A5122
Rear Shock Absorber Arms, complete	1	1A5114

TOOLS

Valve grinding-in tool	1	9C170
Spanner for dynamo casing nut	1	2H96

WHEELS

Road Wheels complete (for 3.50-19 tyres)	5	1A8018
Spokes, long	60	1A8023
Spokes, short	120	1A8024

THE AUSTIN MOTOR CO., LTD. NORTHFIELD, BIRMINGHAM.

G.P.O. Box 41.

Telephone: Priory 2101. Telegrams: "Speedily, Telex, Northfield."
Cables: "Speedily, Birmingham, England." Code: Bentley's.

London Showrooms:

479-483, OXFORD STREET, W.1.

Telephone: Mayfair 7620 Telegrams: "Austinette, Telex, London."

London Service Depots:

25-27, NORTH ROW, OXFORD STREET, W.1. (Nr. Marble Arch)

Telephone: Mayfair 6271

HOLLAND PARK HALL.

HOLLAND PARK AVENUE, W.11.

Telephone: Park 8001

